



1.00 Perimeter Edge Upstand Detail

- 1 CAVITY TRAY IF PRESENT MUST BE SITUATED ABOVE LEAD FLASHING 'BY BRICKWORK CONTRACTOR'
- 2 LEAD FLASHING TO BE LEAD PLUGGED TO HOLD FLASHING. PLUGS TO BE FIXED AT 300mm CENTRES. CHASE & FLASHING TO BE POINTED IN MASTIC SEALANT 'BY PLUMBER'
- 3 PIR 30MM FOIL FACED INSULATION
- 4 ALKOR-METAL TRIM FIXED TO MASONRY (AT 250 c/s)
- 5 HEAT WELD
- 7 PVC-U DRAINAGE TRIM
- 8 ALKORPLAN 35176 MEMBRANE
- 9 SEDUM FOLIAGE
- 10 ALKOR-METAL TRIM
- 11 SEDUM BLANKET 81017
- 12 DRAINAGE MAT 81015
- 13 ALKORPLAN 35177LA 1.5MM THICK MEMBRANE
- 14 ALKORPLUS 81068 PU ADHESIVE
- 15 PIR INSULATION GLASS TISSUE FACED
- 16 ALKORPLUS 81002 SELF ADHESIVE VAPOUR CONTROL LAYER
- 17 ALKORPLUS 81016 WATER RETENTION LAYER
- 18 ALKORPLUS 81014 SLIP LAYER
- 27 ALKORPLAN 35177 NOT FLEECE BACKED
- 28 ALKORPLUS 81168 PU ADHESIVE